



Mobilité



Apple

## Restoring call and text reception (Apple)

Not receiving calls or text messages on your mobile device?  
Here are some things to check:

### > Restart your mobile phone

### > Disable Do Not Disturb mode

**Do Not Disturb**  mode mutes calls when your mobile phone is locked.

- 1 Go to **Settings**, then **Focus**.
- 2 Tap **Do Not Disturb**.
- 3 Under **Turn on Automatically**, disable **Do Not Disturb** mode.

### > Make sure your phone has access to the network

- 1 If you're using a new SIM card, **make sure it's activated**.
- 2 If you see the  icon in your device's status bar or at the top of the screen, **disable Airplane mode**.
- 3 **Check that data is enabled** in your device settings.
- 3 Check whether your device is connected to the **Videotron** or **Videotron-Ext** network.

### > Check whether you've blocked the caller's number

### > Make sure Call Forwarding is disabled



For more information on incoming call and text issues, direct the camera towards the QR code.  
Find all our tips at [www.videotron.com/en/support](http://www.videotron.com/en/support)

